



# **R906-26GHz Radar Level Meter**



#### **BEST MEASUREMENT PERFORMANCE**

- Best measurement performance on solid
- Optimum level measurement
- Reliable level measurement for the most complicate applications
- Excellent design to reduce installation cost and eliminate daily maintenance

### **BEST FIT- FOR- APPLICATION**

- Wide range up to 20 meters
- Wide application of Solid material, Strong dust, easy to crystallize, condensation condition
- Wide variety of I/O and expansive communication protocols

### Copyright © 2020 Reliant Instruments Inc. All Rights Reserved

No part of this publication may be copied or distributed, transmitted, transcribed, stored in a retrieval system, or translated into any human or computer language, in any form or by any means, electronic, mechanical, manual, or otherwise, or disclosed to third parties without the express written permission. The information contained in this manual is subject to change without notice.




### **OVERVIEW**

This series of radar level meter adopted 26G high frequency radar sensor, the maximum measurement range can reach up to 30 meters. Antenna is optimized further processing, the new fast microprocessors have higher speed and efficiency can be done signal analysis, the instrumentation can be used for reactor, solid silo and very complex measurement environment.

### PRINCIPLE

Radar level transmitter antenna microwave pulse is narrow, the downward transmission antenna. Microwave exposure to the medium surface is reflected back again by the antenna system receives, sends the signal to the electronic circuit automatically converted into level signals (because the microwave propagation speed, electromagnetic wave to reach the target and the reflected back to the receiver this time is almost instantaneous).



Datum measurement: Screw thread bottom or the sealing surface of the flange.

Note: Make sure the radar level meter the highest level cannot enter the measuring blind area (Figure

D shown below).

### **DESIGN & BENEFIT**

- Small antenna size, easy to install; Non-contact radar, no wear, no pollution.
- Almost no corrosion, bubble effect; almost not affected by water vapor in the atmosphere, the temperature and pressure changes.
- Serious dust environment on the high level meter work has little effect.
- A shorter wavelength, the reflection of solid surface inclination is better.
- Beam angle is small, the energy is concentrated, can enhance the ability of echo and to avoid interference.
- The measuring range is smaller, for a measurement will yield good results.



- High signal-to-noise ratio, the level fluctuation state can obtain better performance.
- High frequency, measurement of solid and low dielectric constant of the best choice.

### **APPLICATION**

### Industries

- Chemicals
- Food & Beverages
- Machinery
- Minerals & Ming
- Oil & Gas

- Pharmaceuticals
- Power Plant
- Pulp & Paper
- Water
- Waste Water


### **TECHNICAL PARAMETERS**

Process Connection	Flange			
Antenna Material	PTFE/ Stainless Steel			
The outer shell				
Seal material of shell and shell	Silicone rubber			
Casing window	Polycarbonate			
Casing window	Polycarbonate			
The ground terminal	Stainless steel			
Power Supply	1			
2-wire system	Standard type(16 to 26) V DCIntrinsically safe(21.6 to 26.4) V DCPower dissipationmax 22.5mA / 1WAllowable ripple<100Hz			
Flameproof	(100 to 100K) Hz Uss <i0mv (22.8 to 26.4) V DC, 2-wire system (198 to 242)VAC, 4-wire system/110VAC, 4-wire system</i0mv 			
Cable parameters				
Cable entrance / plug	1-M20x1.5 cable entrance,1- blind plug			
Terminal	Conductor cross section 2.5mm <sup>2</sup>			
Output and Communication				
Output signal	(4 to 20) mA/RS485			
Communication protocol	HART/ Modbus			
Resolution	1.6µA			
Fault signal	Constant current output; 20. 5mA, 22mA ,3.9mA			



Integral time	(0 to 36) s, adjustable		
Blind area	the ends of the antenna		
Max. distance measurement	20 meters		
Accuracy	± 3 mm		
Display	LCD, Programmable		
Enclosure	IP67		
Ex-Grade	Exia II C T6 Ga/ Exd II C T6 Gb		
Frequency	26GHz		
Communication interface	HART communication protocol		
Measurement interval	about 1 second (depend on parameter settings)		
Adjust the time	about 1 second (depend on parameter settings)		
Display resolution	1 mm		
Storage temperature	(-40 to 100) °C		
Process Temperature	(-40 to 130)℃ / (-40 to 250)℃		
Pressure	Max. 4.0MPa		
Seismic	Mechanical vibration I0m/s <sup>2</sup> , (10 to 150) Hz		

### LINEARITY





### **MODEL SELECTION**

• R906-

#### Туре

- P Standard (Non-explosion-proof)
- I Intrinsically safe (Exia IIC T6 Ga)
- G Flameproof Type (Exd IIC T6 Gb)

#### **Process Connection / Material**

- B Flange DN80 / PTFE
- C Flange DN100 / PTFE
- D Flange DN150 / PTFE
- E Flange DN80 / Stainless Steel 304
- F Flange DN100 / Stainless Steel 304
- G Flange DN150 / Stainless Steel 304
- Y Special Custom Made

#### Seal Up / Process Temperature

V Viton / (-40~130) ℃

#### **Electronic Unit**

- 3 (4~20) mA / 24V DC / HART 2-wire system
- 4 (4~20) mA / 220V AC / HART 4- wire system
- 5 RS485 / Modbus / 6~24V/ Four wire system

#### Outer Covering / Protection Grade

- L Aluminum / Single chamber / IP67
- H Aluminum / Double chamber / IP67
- G Plastic / Single chamber / IP65
- K Stainless steel / Single chamber / IP67

#### **Cable Line**

M M 20x1.5

N 1/2" NPT

#### Field Display/The Programmer

- A With
- X Without



### **INSTALLATION**


- 1. The Installation Requirements
- Installation guide:

Be installed in the diameter of the 1/4 or 1/6. Avoid installing in the center of the tank.

Note: 1) datum

2 The container center or axis of symmetry

• Take over the installation diagram:



D

### • Typical installation errors:

Conical tank cannot be installed above the feed port.
*Note*: outdoor installation should adopt sunshade.

Т


- ① Correct rainproof measures
- ② Error



The instrument cannot be installed in the arched or domed roof intermediate. In addition to produce indirect echo is also affected by the echoes. Multiple echo can be larger than the real value of signal echo, because through the top can concentrate multiple echo. So cannot be installed in a central location.



② Error




> There are obstacles affecting measurement needed reflection plate.



2 Error

The reflecting plate is the role of refraction disturbance signal



### **ELECTRICAL CONNECTION**

### • The power supply voltage:

(4to20)mA/HART	The power supply and the output current signal sharing a two core shield
(2-wire system)	cable. The supply voltage range see technical data. For intrinsically safe
	type must be a safety barrier between the power supply and the instrument.
(4to20)mA/HART	Separate power supply and the current signal, respectively using a
(4-wire system)	two-core shielded cable. The supply voltage range see technical data.
RS485 / Modbus	Power supply and Modbus signal line separated respectively using a
	two-core shielded cable, the power supply voltage range see technical
	data.

 $\geq$ 

 $\triangleright$ 



Connection mode: 24V two wire wiring diagram as right: 24V (4-20)mA + Connection (4


### • Explosion Proof Connection

The intrinsic safety version sensors (Exia IIc T6) use Alu-die casting housing and filling Silicone rubber sealants internal structure aimed to prevent sparks resulted from circuit failure from leaking out. It is applicable for the continuous level measurement of flammable medium under Exia IIc T6.


A safety barrier FBS-2 must be used together with the intrinsic safety instrument. It is an associated device to this product for the power supply of this product. The main specification is intrinsic safety: Exia IIC, voltage of power supply:  $24VDC \pm 5\%$ , short-circuit current: 135mA, operating current: 4 to 20mA.



All cables must be shielded. The max length is 500m for the cable from the barrier to the sensor. Stray capacitor  $\leq 0.1 \ \mu$  F/Km, stray inductance 1mH/Km. Instrument must be connected to the ground potential. Any unapproved associated device is not allowed to be used.



Adjustment with Software



Adjustment with HART Handheld Programmer




### • Safety instructions:

- > Please observe the local electrical code requirements!
- Please comply with local requirements for personnel health and safety regulations. All electrical components of instrument operation must be completed by the formal training of professionals.
- Please check the instrument nameplate to provide product specifications meet your requirements. Please make sure that the power supply voltage and instrument nameplate on the requirements.

### • Enclosure grade:

This instrument meets the enclosure class IP66/67 requirements, please ensure the waterproof cable sealing head. The following diagram:



#### How to install to meet the requirements of IP67:

Please make sure that the sealing head is not damaged.

Please make sure that the cable is not damaged.

Please make sure that the cable for use with electrical connection specification.

3

Cable into the electrical interface before its curved downward, ensure that the water will not flow into the shell, see the 1

Tighten the cable seal head, see the 2

Please electrical interface will not use blind plug tight, see the ③

### **INSTRUMENT COMMISSIONING**


- There are three kinds of debugging method:
  - 1) Display / Keyboard
  - 2) Host debugging
  - 3) HART handheld programmer



### • Display / Keyboard:

Please debug the instrumentation by four buttons on the display screen. There are three debug menu languages optional. After debugging is generally used only for display, through the glass window can read measured value very clearly.

Display / Keyboard




- 1) Liquid crystal display(LCD)
- 2 The key

### • PC debugging:


Connected to PC by HART

- ① RS232 interface or USB interface
- 2 Radar level meter
- ③ HART adapter
- (4) 250  $\Omega$  resistor




### HART handheld programmer:


- ① HART handheld programmer
- 2 Radar level meter
- ③ 250 Ωresistor






- 2. Structure Size (Unit: mm)
- The outer shell:









• Appearance size:





Flange	Trumpet diameter D	Trumpet height H	
DN80	Φ76	80	
DN100	Φ76	80	

• Flange type:



Size	D	К	n	L
DN80	Ф200	Ф160	8	18
DN100	Ф220	Ф180	8	18



### Level Meter Selection Parameter Table

Customer informat	ion				
Company:			Contact:		
Address:					
Tel:			_ Mobile pho	one:	
E-mail:			_ Date:		
License	lon overlagion proof)	- Intrincically acfo (C			
	lon-explosion-proof)				
□ Intrinsically safe (Ex	,	Intrinsically safe+ma	nne license (Ex	la lic 10 Ga)	
□ Flame proof (Exd I					
Tank / Container In	formation				
The Types of Tank:					
□ Tank	Reaction Tank	Separation	Tank	□ Marine Tank	
The Tank Structure:					
Material of Tank:			Pressure:		
Tank size:					
Tank Height:		m	Diameter:		
The top of the tank:					
□ Vault	□ Flat	🗆 Open		Cone type	
The bottom of the tan	k:			21	
Cone bottom	□ Flat	□ Slope I	bottom	□ Arc bottom	
Installation:					
Top installation		Side insta	allation		
□ The bypass pipe mo	ount	Guided wave pi	pe installation		
Installation takes over	r the top of the tank	(information):			
Height of take over :	r	nm Diameter o	f take over :		mm
Measurement of Me	edium				
Media name:	🗆 Liquid	□ Solid		Mixed Media	
Medium temperature:				°C	
Dielectric Constant:					
Linked material:	□ Yes	□ No			
Mixing:	□ Yes	□ No			
Process Connect	ion				
Thread:	□ G1½″ A	□ 1½″ NPT			
Flange	□ Flange (DN=	) 🗆 🗆 Fla	nge (ANSI=	)	
Power supply:					
□ 24V DC Two wire sys		our wire system	□ 220V AC Fo	ur wire system	
		HART			
Display: D Take th	ne meter display progra	Im	Without meter	er display program	



## Warning

• Ensure the explosion-proof class marked on the nameplate to meet or exceed the required rating of the relevant installation environment.

• Ensure that the enclosure rating indicated on the nameplate to meet the requirements of the installation environment.

• Ensure that the ambient and process temperature ranges marked on the nameplates to meet the application requirements.

### **CONTACT INFORMATION**

#### **Reliant Instruments Inc.**

16655 Telge Road, Cypress, TX 77429, USA Phone: (+1) 281 224 2457 Email: <u>sales@reliantinstruments.com</u> <u>www.reliantinstruments.com</u>

### Shanghai Representative Office

320 Building 4, 299 Songqiu Road, Shanghai 201703 China Mobile: (+86) 137 8890 0279

Email: steven.shao@reliantinstruments.com

www.reliantinstruments.com

